
17
17.1
17.2
7
1
2
3
FCD, XFCD
4
4.1
4.2
4.3
4.4
15
8
13
12
11
10
9
14
16
5
6


Activate system
100
Restrictive mode
200
no
Activate call signal
250
Accept call
270
yes
Activate restrictive mode
280
Offer communications function
300
Select communications function
400
Cut link
500
Connect to mailbox
Activate call signal
Maintain link and activate call signal after delay
510
520
530